

RIPSHIFT

AUSTRALIA'S FASTEST SHIFTER
WWW.RIPSHIFT.COM.AU

A Division of GM Motorsport
23 Reserve Road Melton Vic 3337
Phone 03 9746 6656 - Fax 03 9746 6646
sales@gmmotorsport.com.au

Congratulations on the Purchase of your VE Auto RipShift Handle

Installation Instructions for Holden & HSV VE Ripshift Auto Handle

Tools Required

Short Flat Head Screwdriver
Short Phillips Screwdriver
Allen Keys (Supplied)



1. Put gear shifter into drive with handbrake on. (please be cautious of car rolling)
Remove rear plastic trigger cap with a flat head screw driver



2. Using your phillips head screwdriver remove the inner screw



3. Once inner screw is removed you can remove the front cover



4. Pull front silver plastic divider out, please take note, the bottom circlip will also be removed.

*You will reuse the circlip on your new RipShift



5. Pull the original shifter body off the shaft



6. On your new RipShift, undo both side cover panels with supplied Allen key (2.5mm)



7. Install the original circlip removed in step 4, place clip in lower section of your new RipShift (please refer to photo)



8. Slide shifter down (it may be firm) make sure clip goes over shaft and slide shifter down until it locks into place.



9. Tighten the grub screws on both sides as pictured. Before putting on side covers, ensure shifter works and shifts as required.



10. Place side covers and screw down with supplied Allen key



Installed, Enjoy!

Congratulations you have installed your new VE Auto Ripshift Handle

**If you have any trouble or need to ask any questions please contact us direct by
Phone 03 9746 6656 or
Email sales@gmmotorsport.com.au**